

# Waste Elimination



## P2 Laboratories

### General instructions

All waste must be inactivated in the building before elimination.

### Solid waste

- ▶ Contaminated solid waste must be collected in a bin for P2 waste. Full bags must be autoclaved.
- ▶ Non-contaminated solid wastes are collected in the laboratory's bin. Full bags are deposited outside the laboratory.



### Liquid waste

- ▶ Liquid waste must be inactivated by bleach or by another appropriate disinfectant.
- ▶ Allow the bleach act for 15 min.
- ▶ Dispose of the mixture in the sink.



15'



### Sharp waste

- ▶ Pointed or sharp waste must be collected in the yellow boxes "sharps".
- ▶ These boxes, closed, must be autoclaved.
- ▶ Yellow boxes, closed and labeled as "Déchets spéciaux", are brought to the Special Wastes office.



### Glass waste

- ▶ Glass waste must be collected in bins.
- ▶ These bins, closed, must be autoclaved.
- ▶ These bins, labeled as "Déchets spéciaux", are brought to the Special Wastes office.



### Contact

[dechets-speciaux@sciences.unige.ch](mailto:dechets-speciaux@sciences.unige.ch)



UNIVERSITÉ  
DE GENÈVE

[STEPS]

santé au travail • environnement • prévention • sécurité